



Samsung SGH-E317 SIM Card Replacement

Replacing the SIM card in the Samsung SGH-E317.

Written By: Laura MacCarley



INTRODUCTION

In this guide, we will be replacing the SIM card in the Samsung SGH-E317.



TOOLS:

- [iFixit Opening Tools](#) (1)
-

Step 1 — Battery



- Remove the back panel by pressing up on switch, located at the top on the back of the phone.
- ❗ You may want to use a plastic opening tool to help pry the back panel off.

Step 2 — SIM Card



- Gently slide the SIM card into the slot, oriented as in the picture.

To reassemble your device, follow these instructions in reverse order.